

AssayMax™ Human Factor V ELISA Kit

Assaypro LLC 3400 Harry S Truman Blvd St. Charles, MO 63301 T (636) 447-9175 F (636) 395-7419 www.assaypro.com

For any questions regarding troubleshooting or performing the assay, please contact our support team at support@assaypro.com.

Thank you for choosing Assaypro.

Assay Summary

Step 1. Add 50 μ l of Standard or Sample per well. Incubate 2 hours.

Step 2. Wash, then add 50 μ l of Biotinylated Antibody per well. Incubate 1 hour.

Step 3. Wash, then add 50 μ l of SP Conjugate per well. Incubate 30 minutes.

Step 4. Wash, then add 50 μ l of Chromogen Substrate per well. Incubate 15 minutes.

Step 5. Add 50 μ l of Stop Solution per well. Read at 450 nm immediately.

Symbol Key



Consult instructions for use.

Assay Template

12								
11								
10								
6								
80								
7								
9								
4								
8								
2								
1								
	٧	В	C	Q	E	Ŧ	ט	I

AssayMax™ Human Factor V (Factor 5) ELISA Kit

Catalog No. EF1005-8

Sample insert for reference use only
Positive and Low Controls Included

Introduction

Factor V (FV) is an essential cofactor of the blood coagulation cascade and circulates in plasma as a large single-chain glycoprotein (330 kDa). The deduced amino acid sequence consists of 2224 amino acids inclusive of a 28-amino acid leader peptide (1). During coagulation, it is converted to the active cofactor FVa via limited proteolysis by thrombin and is spliced into a heavy chain (110 kDa) and a light chain (73 kDa) held together non-covalently by calcium (2). In the presence of a calcium ion and the phospholipid on cell surfaces, FVa and FXa form the prothrombinase complex, which catalyzes the hydrolysis of prothrombin to thrombin (3). Then thrombin cleaves fibrinogen to fibrin, which polymerizes to form a clot. FVa is readily inactivated by anticoagulant activated protein C (4). FV Leiden, a single amino acid mutation, renders FVa resistant to cleavage by activated protein C. It, therefore, overproduces thrombin and leads to excess clotting and hereditary thrombophilia disorder (5). Severe FV deficiency is associated with mild to severe bleeding diathesis (6).

Principle of the Assay

The AssayMax™ Human Factor V ELISA (Enzyme-Linked Immunosorbent Assay) Kit is designed for detection of factor V in human plasma, milk, urine, CSF, and cell culture samples. This assay employs a quantitative sandwich enzyme immunoassay technique that measures human factor V in approximately 4 hours. A polyclonal antibody specific for human factor V has been pre-coated onto a 96-well microplate with removable strips. Factor V in standards and samples is sandwiched by the immobilized antibody and a biotinylated polyclonal antibody specific for human factor V, which is recognized by a streptavidin-peroxidase (SP) conjugate. All unbound material is washed away and a peroxidase enzyme substrate is added. The color development is stopped and the intensity of the color is measured.

Caution and Warning

 This product is for Research Use Only and is not intended for use in diagnostic procedures.

- Prepare all reagents (diluent buffer, wash buffer, standard, biotinylated antibody, and SP conjugate), as instructed, prior to running the assay.
- Prepare all samples prior to running the assay. The dilution factors for the samples are suggested in this insert. However, the user should determine the optimal dilution factor.
- Spin down the SP conjugate vial and the biotinylated antibody vial before opening and using contents.
- The Stop Solution is an acidic solution.
- The kit should not be used beyond the expiration date.

Reagents

- Human Factor V Microplate: A 96-well polystyrene microplate (12 strips of 8 wells) coated with a polyclonal antibody against human factor V.
- Sealing Tapes: Each kit contains 3 precut, pressure sensitive sealing tapes that can be cut to fit the format of the individual assay.
- Human Factor V Standard: Human factor V in a buffered protein base (19.5 ng, lyophilized).
- Biotinylated Human Factor V Antibody (50x): A 50-fold concentrated biotinylated polyclonal antibody against human factor V (120 µl).
- EIA Diluent Concentrate (10x): A 10-fold concentrated buffered protein base (30 ml).
- Wash Buffer Concentrate (20x): A 20-fold concentrated buffered surfactant (30 ml, 2 bottles).
- SP Conjugate (100x): A 100-fold concentrate (80 μl).
- Chromogen Substrate (1x): A stabilized peroxidase chromogen substrate tetramethylbenzidine (7 ml).
- Stop Solution (1x): A 0.5 N hydrochloric acid solution to stop the chromogen substrate reaction (11 ml).
- **Positive Control:** 1 vial, lyophilized. See insert CEF10051.
- Low Control: 1 vial, lyophilized. See insert CEF10052.

Storage Condition

- Upon arrival, immediately store components of the kit at recommended temperatures up to the expiration date.
- Store Standard, SP Conjugate, and Biotinylated Antibody at -20°C.
- Store Microplate, Diluent Concentrate (10x), Wash Buffer, Stop Solution, and Chromogen Substrate at 2-8°C.
- Unused microplate wells may be returned to the foil pouch with the desiccant packs and resealed. May be stored for up to 30 days in a vacuum desiccator.

Other Supplies Required

- Microplate reader capable of measuring absorbance at 450 nm
- Pipettes (1-20 μl, 20-200 μl, 200-1000 μl, and multiple channel)
- Deionized or distilled reagent grade water

Sample Collection, Preparation, and Storage

- Plasma: Collect plasma using one-tenth volume of 0.1 M sodium citrate as an anticoagulant. Centrifuge samples at 3000 x g for 10 minutes and collect plasma. A 25000-fold sample dilution is suggested into EIA Diluent; however, user should determine optimal dilution factor depending on application needs. The undiluted samples can be stored at -20°C or below for up to 3 months. Avoid repeated freeze-thaw cycles (EDTA or Heparin can also be used as an anticoagulant).
- **Milk:** Collect milk using sample tube. Centrifuge samples at 800 x g for 10 minutes. The sample is suggested for use at 1x or within the range of 2x 10x into EIA Diluent; however, user should determine optimal dilution factor depending on application needs. The undiluted samples can be stored at -20°C or below for up to 3 months. Avoid repeated freeze-thaw cycles.
- Urine: Collect urine using sample pot. Centrifuge samples at 800 x g for 10 minutes. The sample is suggested for use at 1x or within the range of 2x 10x into EIA Diluent; however, user should determine optimal dilution factor depending on application needs. The undiluted samples can be stored at -20°C or below for up to 3 months. Avoid repeated freeze-thaw cycles.
- CSF: Collect cerebrospinal fluid (CSF) using sample pot. Centrifuge samples at 3000 x g for 10 minutes. A 2-fold sample dilution is suggested into EIA Diluent or within the range of 1x 10x; however, user should determine optimal dilution factor depending on application needs. The undiluted samples can be stored at -80°C for up to 3 months. Avoid repeated freeze-thaw cycles.
- Cell Culture Supernatant: Centrifuge cell culture media at 1500 rpm for 10 minutes at 4°C to remove debris and collect supernatant. If necessary, dilute samples into EIA Diluent; user should determine optimal dilution factor depending on application needs. The undiluted samples can be stored at -80°C. Avoid repeated freeze-thaw cycles.

Applicable samples may also include biofluids, cell culture, and tissue homogenates. If necessary, user should determine optimal dilution factor depending on application needs.

Refer to Dilution Guidelines for further instruction.

	Guidelines for Dilutions of 100-fold or Greater (for reference only; please follow the insert for specific dilution suggested)				
100x		10000x			
A)	4 μl sample : 396 μl buffer (100x) = 100-fold dilution Assuming the needed volume is less than or equal to 400 μl.	A) B)	4 μl sample : 396 μl buffer (100x) 4 μl of A : 396 μl buffer (100x) = 10000-fold dilution Assuming the needed volume is less than		
	1000x		or equal to 400 μl. 100000 x		
A) B)	4 μl sample : 396 μl buffer (100x) 24 μl of A : 216 μl buffer (10x) = 1000-fold dilution Assuming the needed volume is less than or equal to 240 μl.	A) B) C)	4 μl sample : 396 μl buffer (100x) 4 μl of A : 396 μl buffer (100x) 24 μl of B : 216 μl buffer (10x) = 100000-fold dilution Assuming the needed volume is less than or equal to 240 μl.		

Reagent Preparation

- Freshly dilute all reagents and bring all reagents to room temperature before use.
- **EIA Diluent Concentrate (10x):** Dilute the EIA Diluent Concentrate 10-fold with reagent grade water to produce a 1x solution. When diluting the concentrate, make sure to rinse the bottle thoroughly to extract any precipitates left in the bottle. Mix the 1x solution gently until the crystals have completely dissolved. Store for up to 30 days at 2-8°C.
- Human Factor V Standard: Reconstitute the Human Factor V Standard (19.5 ng) with 0.65 ml of EIA Diluent to generate a 30 ng/ml standard stock solution. Allow the vial to sit for 10 minutes with gentle agitation prior to making dilutions. Prepare duplicate or triplicate standard points by serially diluting from the standard stock solution (30 ng/ml) 4-fold with EIA Diluent to produce 7.5, 1.875, 0.469, and 0.117 ng/ml solutions. EIA Diluent serves as the zero standard (0 ng/ml). Aliquot remaining stock solution to limit repeated freeze-thaw cycles. This solution should be stored at -20°C and used within 5 days.

Standard Point	Dilution	[FV] (ng/ml)
P1	1 part Standard (30 ng/ml)	30
P2	1 part P1 + 3 parts EIA Diluent	7.5
Р3	1 part P2 + 3 parts EIA Diluent	1.875
P4	1 part P3 + 3 parts EIA Diluent	0.469
P5	1 part P4 + 3 parts EIA Diluent	0.117
P6	EIA Diluent	0.0

- Biotinylated Human Factor V Antibody (50x): Spin down the antibody briefly and dilute the desired amount of the antibody 50-fold with EIA Diluent to produce a 1x solution. The undiluted antibody should be stored at -20°C.
- Wash Buffer Concentrate (20x): Dilute the Wash Buffer Concentrate 20fold with reagent grade water to produce a 1x solution. When diluting
 the concentrate, make sure to rinse the bottle thoroughly to extract any
 precipitates left in the bottle. Mix the 1x solution gently until the crystals
 have completely dissolved.
- SP Conjugate (100x): Spin down the SP Conjugate briefly and dilute the
 desired amount of the conjugate 100-fold with EIA Diluent to produce a
 1x solution. The undiluted conjugate should be stored at -20°C.

Assay Procedure

- Prepare all reagents, standard solutions, and samples as instructed. Bring all reagents to room temperature before use. The assay is performed at room temperature (20-25°C).
- Remove excess microplate strips from the plate frame and return them immediately to the foil pouch with desiccants inside. Reseal the pouch securely to minimize exposure to water vapor and store in a vacuum desiccator.
- Add 50 µl of Human Factor V Standard or sample to each well. Gently tap
 plate to thoroughly coat the wells. Break any bubbles that may have
 formed. Cover wells with a sealing tape and incubate for 2 hours. Start
 the timer after the last addition.
- Wash the microplate manually or automatically using a microplate washer. Invert the plate and decant the contents; hit 4-5 times on absorbent material to completely remove the liquid. If washing manually, wash five times with 200 μl of Wash Buffer per well. Invert the plate each time and decant the contents; hit 4-5 times on absorbent material to completely remove the liquid. If using a microplate washer, wash six times with 300 μl of Wash Buffer per well; invert the plate and hit 4-5 times on absorbent material to completely remove the liquid.
- Add 50 µl of Biotinylated Human Factor V Antibody to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed. Cover wells with a sealing tape and incubate for 1 hour.
- Wash the microplate as described above.
- Add 50 µl of SP Conjugate to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed. Cover wells with a sealing tape and incubate for 30 minutes. Turn on the microplate reader and set up the program in advance.
- Wash the microplate as described above.
- Add 50 µl of Chromogen Substrate to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed.

- Incubate in ambient light for 15 minutes or until the optimal blue color density develops.
- Add 50 µl of Stop Solution to each well. The color will change from blue to yellow. Gently tap plate to ensure thorough mixing. Break any bubbles that may have formed.
- Read the absorbance on a microplate reader at a wavelength of 450 nm immediately. If wavelength correction is available, subtract readings at 570 nm from those at 450 nm to correct optical imperfections.
 Otherwise, read the plate at 450 nm only. Please note that some unstable black particles may be generated at high concentration points after stopping the reaction for about 10 minutes, which will reduce the readings.

Data Analysis

- Calculate the mean value of the duplicate or triplicate readings for each standard and sample.
- To generate a standard curve, plot the graph using the standard concentrations on the x-axis and the corresponding mean 450 nm absorbance (OD) on the y-axis. The best fit line can be determined by regression analysis using log-log or four-parameter logistic curve fit.
- Determine the unknown sample concentration from the Standard Curve and multiply the value by the dilution factor.

Typical Data

The typical data is provided for reference only. Individual laboratory
means may vary from the values listed. Variations between laboratories
may be caused by technique differences.

Standard Point ng/ml		OD	Average OD
P1	30	2.081	2.102
rı	30	2.123	2.102
P2	7.5	1.900	1.888
r Z	7.5	1.876	1.000
P3 1.875		1.274	1.265
ro	1.875	1.256	1.203
P4	0.469	0.596	0.617
P4		0.638	0.017
DE	P5 0.117		0.261
ro	0.117	0.267	0.201
P6	0.0	0.112	0.109
PU	0.0	0.106	0.109
Sample: Poo	oled Normal	0.449	0.460
Sodium Citrate I	Plasma (25000x)	0.487	0.468

Standard Curve

 The curve is provided for illustration only. A standard curve should be generated each time the assay is performed.

Human Factor V Standard Curve

[H. Factor V] (ng/ml)

R² = 0.999

Performance Characteristics

- The minimum detectable dose of human factor V as calculated by 2SD from the mean of a zero standard was established to be 49 pg/ml.
- Intra-assay precision was determined by testing three plasma samples twenty times in one assay.
- Inter-assay precision was determined by testing three plasma samples in twenty assays.

	Intra-Assay Precision			Inter-Assay Precision		
Sample	1	2	3	1	2	3
n	20	20	20	20	20	20
CV (%)	4.4%	4.8%	5.1%	9.9%	11.2%	11.5%
Average CV (%)	4.8%				10.9%	_

Spiking Recovery

 Recovery was determined by spiking two plasma samples with different factor V concentrations.

Sample	Unspiked Sample (ng/ml)	Spiking Value (ng/ml)	Expected	Observed	Recovery (%)
		2.5	7.7	8.1	105%
1	1 5.2	5.0	10.2	10.3	101%
		10.0	15.2	14.9	98%
		2.5	4.9	5.4	110%
2	2.4	5.0	7.4	7.5	101%
		10.0	12.4	11.9	96%
Average Recovery (%)					102%

Linearity

Plasma samples were serially diluted to test for linearity.

Average Percentage of Expected Value (%)		
Sample Dilution	Plasma	
12500x	99%	
25000x	102%	
50000x	99%	

Cross-Reactivity

Species	Cross-Reactivity (%)
Canine	None
Monkey	6%
Mouse	None
Rat	None
Swine	3%
Rabbit	None

 No significant cross-reactivity observed with factor I (fibrinogen), factor II (prothrombin), factor III (tissue factor), factor VII, factor IX, factor X, factor XI, factor XIII, and VWF.

Troubleshooting

Use of improper components Check the expiration date listed before use. Do not interchange components from different lots. Check that the correct wash buffer is being used. Check that all wells are empty after aspiration. Check that all wells are empty after aspiration. Check that the microplate washer is dispensing proper if washing by pipette, check for proper pipetting technique. Splashing of reagents while loading wells Inconsistent volumes loaded into wells Insufficient mixing of reagent dilutions Improperly sealed microplate Microplate was left unattended between steps Omission of step Steps performed in incorrect order Insufficient amount of reagents added to wells Wash step was skipped Improper wash buffer Insufficient or prolonged incubation 1 consult the provided procedure for correct incubation time. Check that the correct wash buffer is being used. Check that the microplate pouch has no punctures. Check that the provided procedure for complete list of ste steps Consult the provided procedure for the correct order. Improper wash buffer Improper wash buffer Improper reagent preparation Insufficient or prolonged incubation Consult the provided procedure for correct incubation time.	
Improper wash step Check that the correct wash buffer is being used. Check that all wells are empty after aspiration. Check that the microplate washer is dispensing proper If washing by pipette, check for proper pipetting technique. Splashing of reagents while loading wells Inconsistent volumes loaded into wells Insufficient mixing of reagent dilutions Insufficient mixing of reagent dilutions Improperly sealed microplate Microplate Microplate was left Check that the correct wash buffer is being used. Pheck that the microplate washer is dispensing proper of the proper pipetting technique. Pipette properly in a controlled and careful manner. Check pipette calibration. Check pipette for proper performance. Thoroughly agitate the lyophilized components after reconstitution. Thoroughly mix dilutions. Check that the microplate pouch for proper sealing. Check that the microplate pouch has no punctures. Check that there desiccants are inside the microplate pouch prior to sealing. Each step of the procedure should be performed	
Improper wash step Ocheck that all wells are empty after aspiration. Check that the microplate washer is dispensing proper if washing by pipette, check for proper pipetting technique. Splashing of reagents while loading wells Inconsistent volumes loaded into wells Insufficient mixing of reagent dilutions Insufficient mixing of reagent dilutions Improperly sealed microplate Microplate was left Ocheck that all wells are empty after aspiration. Pipette properly in a controlled and careful manner. Ocheck pipette calibration. Ocheck pipette calibration. Thoroughly agitate the lyophilized components after reconstitution. Thoroughly mix dilutions. Ocheck that the microplate pouch has no punctures. Check that three desiccants are inside the microplate pouch prior to sealing. Microplate was left Ocheck that the microplate sould be performed	
Improper wash step	
Splashing of reagents while loading wells Inconsistent volumes loaded into wells Insufficient mixing of reagent dilutions Improperly sealed microplate Microplate was left I Musch was left I Pipette properly in a controlled and careful manner. I Pipette properly in a controlled and careful manner. I Pipette properly in a controlled and careful manner. I Pipette properly in a controlled and careful manner. I Check pipette calibration. I Thoroughly agitate the lyophilized components after reconstitution. I Thoroughly mix dilutions. I Check the microplate pouch for proper sealing. I Check that the microplate pouch has no punctures. I Check that three desiccants are inside the microplate pouch prior to sealing. I Microplate was left I Wusch was left was left with a controlled and careful manner. I Pipette properly in a controlled and careful manner. I Pipette properly in a controlled and careful manner. I Pipette properly in a controlled and careful manner. I Pipette properly in a controlled and careful manner. I Check pipette calibration. I Check the microplate pouch for proper sealing. I Check that the microplate pouch has no punctures. I Check that the microplate pouch prior to sealing. I Check that the microplate pouch prior to sealing.	
Splashing of reagents while loading wells Inconsistent volumes loaded into wells Insufficient mixing of reagent dilutions Improperly sealed microplate Microplate was left technique. Pipette properly in a controlled and careful manner. Pipette properly in a controlled and careful manner. Check pipette calibration. Thoroughly agitate the lyophilized components after reconstitution. Thoroughly mix dilutions. Check the microplate pouch for proper sealing. Check that the microplate pouch has no punctures. Check that three desiccants are inside the microplate pouch prior to sealing. Each step of the procedure should be performed	/ .
Splashing of reagents while loading wells Inconsistent volumes loaded into wells Insufficient mixing of reagent dilutions Improperly sealed microplate Microplate was left Splashing of reagents while loading wells Pipette properly in a controlled and careful manner. Pipette properly in a controlled and careful manner. Check pipette calibration. Thoroughly agitate the lyophilized components after reconstitution. Thoroughly mix dilutions. Check the microplate pouch for proper sealing. Check that the microplate pouch has no punctures. Check that three desiccants are inside the microplate pouch prior to sealing. Microplate was left Each step of the procedure should be performed	
Insufficient mixing of reagent dilutions Improperly sealed microplate Microplate was left Insufficient mixing of reconstitution. Thoroughly mix dilutions. Check the microplate pouch for proper sealing. Check that the microplate pouch has no punctures. Check that three desiccants are inside the microplate pouch prior to sealing. Microplate was left Each step of the procedure should be performed	
Insufficient mixing of reagent dilutions Inproperly sealed microplate Microplate was left Insufficient mixing of reconstitution. Thoroughly agitate the lyophilized components after reconstitution. Thoroughly mix dilutions. Check the microplate pouch for proper sealing. Check that the microplate pouch has no punctures. Check that three desiccants are inside the microplate pouch prior to sealing. Each step of the procedure should be performed	
Insufficient mixing of reagent dilutions Improperly sealed microplate Microplate was left Insufficient mixing of reconstitution. Thoroughly mix dilutions. Check the microplate pouch for proper sealing. Check that the microplate pouch has no punctures. Check that three desiccants are inside the microplate pouch prior to sealing. Microplate was left Each step of the procedure should be performed	
Insufficient mixing of reagent dilutions Improperly sealed microplate Microplate was left Insufficient mixing of reconstitution. Thoroughly mix dilutions. Check the microplate pouch for proper sealing. Check that the microplate pouch has no punctures. Check that three desiccants are inside the microplate pouch prior to sealing. Microplate was left Each step of the procedure should be performed	
Insufficient mixing of reagent dilutions Improperly sealed microplate Microplate was left Insufficient mixing of reconstitution. Thoroughly mix dilutions. Check the microplate pouch for proper sealing. Check that the microplate pouch has no punctures. Check that three desiccants are inside the microplate pouch prior to sealing. Microplate was left Each step of the procedure should be performed	
reagent dilutions Thoroughly mix dilutions. Check the microplate pouch for proper sealing. Check that the microplate pouch has no punctures. Check that three desiccants are inside the microplate pouch prior to sealing. Microplate was left Microplate was left Each step of the procedure should be performed	
Thoroughly mix dilutions. Check the microplate pouch for proper sealing. Check that the microplate pouch has no punctures. Check that three desiccants are inside the microplate pouch prior to sealing. Microplate was left Each step of the procedure should be performed	
Improperly sealed microplate • Check that the microplate pouch has no punctures. • Check that three desiccants are inside the microplate pouch prior to sealing. Microplate was left • Each step of the procedure should be performed	
microplate • Check that three desiccants are inside the microplate pouch prior to sealing. Microplate was left • Each step of the procedure should be performed	
pouch prior to sealing. Microplate was left • Each step of the procedure should be performed	
Microplate was left • Each step of the procedure should be performed	
Omission of step Steps Performed in incorrect order Insufficient amount of reagents added to wells Wash step was skipped Improper wash buffer Improper reagent preparation Insufficient or of the correct order of the correct order of the correct order. Occupant the provided procedure for the correct order. Occupant the provided procedure for all wash steps. Occupant the provided procedure for correct incubation. Occupant the provided procedure for all wash steps. Occupant the provided procedure for correct incubation. Occupant the provided procedure for correct incubation. Occupant the provided procedure for all wash steps. Occupant the provided procedure for the correct wash buffer is being used.	
Omission of step Steps performed in incorrect order Insufficient amount of reagents added to wells Wash step was skipped Improper wash buffer Improper reagent Improper reagen	
Steps performed in incorrect order Insufficient amount of reagents added to wells Wash step was skipped Improper wash buffer Improper reagent preparation Improper reagent preparation Insufficient or complete list of steps	
*Consult the provided procedure for the correct order. Insufficient amount of reagents added to wells Wash step was skipped Improper wash buffer Improper reagent preparation Improper reagent preparation Insufficient or Consult the provided procedure for all wash steps. Consult reagent preparation section for the correct dilutions of all reagents. Consult the provided procedure for correct incubation. Check pipette calibration. Check pipette for proper performance. Check that the correct wash buffer is being used. Consult reagent preparation section for the correct dilutions of all reagents.	JS.
Insufficient amount of reagents added to wells Wash step was skipped Improper wash buffer Improper reagent preparation Insufficient amount of reagents added to wells Consult the provided procedure for all wash steps. Check pipette calibration.	
reagents added to wells Wash step was skipped Improper wash buffer Improper reagent preparation dilutions of all reagents. Insufficient or Consult the provided procedure for all wash steps. Consult the provided procedure for all wash steps. Consult the correct wash buffer is being used. Consult reagent preparation section for the correct dilutions of all reagents.	
wells Wash step was skipped Improper wash buffer Improper reagent preparation Insufficient or wells • Consult the provided procedure for all wash steps. • Check that the correct wash buffer is being used. • Consult reagent preparation section for the correct dilutions of all reagents. Insufficient or • Consult the provided procedure for correct incubation.	
Wash step was skipped Consult the provided procedure for all wash steps. Improper wash buffer Check that the correct wash buffer is being used. Improper reagent preparation Insufficient or Consult the provided procedure for correct incubation.	
Improper wash buffer Check that the correct wash buffer is being used. Improper reagent preparation Insufficient or Consult the provided procedure for correct incubation Consult the provided procedure for correct incubation	
Improper reagent preparation • Consult reagent preparation section for the correct dilutions of all reagents. • Consult the provided procedure for correct incubation	
preparation dilutions of all reagents. Insufficient or • Consult the provided procedure for correct incubation	
Insufficient or • Consult the provided procedure for correct incubation	
E Consultative provided procedure for confect medical con-	
, ,	
periods	
Sandwich ELISA: If samples generate OD values higher the path to be dead as sink (24), dilute assembles.	
than the highest standard point (P1), dilute samples	
further and repeat the assay. Non-optimal sample Non-optimal sample Occupation Further and repeat the assay. Competitive ELISA: If samples generate OD values lowered to the competitive	,
Non-optimal sample of Competitive ELISA: If samples generate OD values lowe than the highest standard point (P1), dilute samples	
further and repeat the assay.	
User should determine the optimal dilution factor for	
samples.	
Non-optimal sample dilution Non-optimal sample dilution Non-optimal sample dilution Samples Contamination of reagents Contents of wells evaporate Pipet dilution Non-optimal sample dilution further and repeat the assay. User should determine the optimal dilution factor for samples. A new tip must be used for each addition of different samples or reagents during the assay procedure. Verify that the sealing film is firmly in place before plat the assay in the incubator or at room temperature. Pipette properly lin a controlled and careful manner.	
reagents samples or reagents during the assay procedure.	
Contents of wells • Verify that the sealing film is firmly in place before place	ing
evaporate the assay in the incubator or at room temperature.	
Pipette properly in a controlled and careful manner.	
Improper pipetting • Check pipette calibration.	
Check pipette for proper performance.	

	nt mixing of t dilutions	 Thoroughly agitate the lyophilized components after reconstitution. Thoroughly mix dilutions.
--	-----------------------------	--

References

- (1) Jenny RJ et al. (1987) Proc Natl Acad Sci USA. 84:4846-4850.
- (2) Esmon CT. (1979) J Biol Chem. 254:964-973.
- (3) Nesheim ME et al. (1981) J Biol Chem. 256:6537-6540.
- (4) Kisiel W et al. (1977) Biochemistry. 16:5824-5831.
- (5) Bertina RM et al. (1994) Nature. 369:64-67.
- (6) Asselta R et al. (2006) J Thromb Haemost. 4(1):26-34.

Version 2.5R-8