



**AssayMax™**  
**Bovine Plasminogen ELISA Kit**

Assaypro LLC  
3400 Harry S Truman Blvd  
St. Charles, MO 63301  
T (636) 447-9175  
F (636) 395-7419  
[www.assaypro.com](http://www.assaypro.com)

For any questions regarding troubleshooting or performing the assay, please contact our support team at [support@assaypro.com](mailto:support@assaypro.com).

Thank you for choosing Assaypro.

## Assay Summary

**Step 1.** Add 50  $\mu$ l of Standard or Sample per well.  
Incubate 2 hours.

**Step 2.** Wash, then add 50  $\mu$ l of Biotinylated Antibody per well.  
Incubate 1 hour.

**Step 3.** Wash, then add 50  $\mu$ l of SP Conjugate per well.  
Incubate 30 minutes.

**Step 4.** Wash, then add 50  $\mu$ l of Chromogen Substrate per well.  
Incubate 25 minutes.

**Step 5.** Add 50  $\mu$ l of Stop Solution per well.  
Read at 450 nm immediately.

## Symbol Key



Consult instructions for use.

## Assay Template

[illegible]



# AssayMax™ Bovine Plasminogen ELISA Kit

Catalog No. EBP1200-1

*Sample insert for reference use only*

## Introduction

Plasminogen (PLG) is a single chain glycoprotein zymogen that is synthesized in the liver and circulated in plasma with a molecular weight of 90 kDa. The N-terminal portion of the molecule is made up of five kringle domains that bind to fibrin. The native molecule has an amino-terminal glutamic acid, known as glu-plasminogen, but can undergo proteolytic cleavage by plasmin to lys-plasminogen (1). The inactive proenzyme plasminogen is converted to the active enzyme plasmin that ultimately digests fibrin. Tissue-type plasminogen activator (tPA) or urokinase-type plasminogen activator (uPA) catalyzes the activation of plasminogen, while plasminogen activator inhibitors (PAIs) inhibit the activation (2). The plasminogen system plays a role in macrophage recruitment, arterial stenosis, atherosclerosis, aneurysm formation, skin and corneal wound healing, glomerulonephritis, and neovascularization (3).

## Principle of the Assay

The AssayMax™ Bovine Plasminogen ELISA (Enzyme-Linked Immunosorbent Assay) Kit is designed for detection of plasminogen in bovine **urine and cell culture samples**. This assay employs a quantitative **sandwich enzyme immunoassay** technique that measures bovine plasminogen in approximately 4 hours. A polyclonal antibody specific for bovine plasminogen has been pre-coated onto a 96-well microplate with removable strips. Plasminogen in standards and samples is sandwiched by the immobilized antibody and a biotinylated polyclonal antibody specific for bovine plasminogen, which is recognized by a streptavidin-peroxidase (SP) conjugate. All unbound material is washed away and a peroxidase enzyme substrate is added. The color development is stopped and the intensity of the color is measured.

## Caution and Warning

- This product is for **Research Use Only** and is not intended for use in diagnostic procedures.
- Prepare all reagents (diluent buffer, wash buffer, standard, biotinylated antibody, and SP conjugate) as instructed, prior to running the assay.
- Prepare all samples prior to running the assay. The dilution factors for the samples are suggested in this insert. However, the user should determine the optimal dilution factor.

- Spin down the SP conjugate vial and the biotinylated antibody vial before opening and using contents.
- The Stop Solution is an acidic solution.
- The kit should not be used beyond the expiration date.

## Reagents

- **Bovine Plasminogen Microplate:** A 96-well polystyrene microplate (12 strips of 8 wells) coated with a polyclonal antibody against bovine plasminogen.
- **Sealing Tapes:** Each kit contains 3 precut, pressure sensitive sealing tapes that can be cut to fit the format of the individual assay.
- **Bovine Plasminogen Standard:** Bovine plasminogen in a buffered protein base (400 ng, lyophilized).
- **Biotinylated Bovine Plasminogen Antibody (50x):** A 50-fold concentrated biotinylated polyclonal antibody against bovine plasminogen (120 µl).
- **MIX Diluent Concentrate (10x):** A 10-fold concentrated buffered protein base (30 ml).
- **Wash Buffer Concentrate (20x):** A 20-fold concentrated buffered surfactant (30 ml, 2 bottles).
- **SP Conjugate (100x):** A 100-fold concentrate (80 µl).
- **Chromogen Substrate (1x):** A stabilized peroxidase chromogen substrate tetramethylbenzidine (7 ml).
- **Stop Solution (1x):** A 0.5 N hydrochloric acid solution to stop the chromogen substrate reaction (11 ml).

## Storage Condition

- Upon arrival, immediately store components of the kit at recommended temperatures up to the expiration date.
- Store SP Conjugate and Biotinylated Antibody at -20°C.
- Store Microplate, Diluent Concentrate (10x), Wash Buffer, Stop Solution, and Chromogen Substrate at 2-8°C.
- Unused microplate wells may be returned to the foil pouch with the desiccant packs and resealed. May be stored for up to 30 days in a vacuum desiccator.
- Store Standard at 2-8°C before reconstituting with Diluent and at -20°C after reconstituting with Diluent.

## Other Supplies Required

- Microplate reader capable of measuring absorbance at 450 nm
- Pipettes (1-20 µl, 20-200 µl, 200-1000 µl, and multiple channel)

- Deionized or distilled reagent grade water

## Sample Collection, Preparation, and Storage

- **Urine:** Collect urine using sample pot. Centrifuge samples at 800 x g for 10 minutes. The sample is suggested for use at 1x; however, user should determine optimal dilution factor depending on application needs. The undiluted samples can be stored at -20°C or below for up to 3 months. Avoid repeated freeze-thaw cycles.
- **Cell Culture Supernatant:** Centrifuge cell culture media at 1500 rpm for 10 minutes at 4°C to remove debris and collect supernatant. If necessary, dilute cell culture media into MIX Diluent; user should determine optimal dilution factor depending on application needs. The undiluted samples can be stored at -80°C. Avoid repeated freeze-thaw cycles.

*Applicable samples may also include biofluids, cell culture, and tissue homogenates. If necessary, user should determine optimal dilution factor depending on application needs.*

**Refer to Dilution Guidelines for further instruction.**

| <b>Guidelines for Dilutions of 100-fold or Greater</b><br><i>(for reference only; please follow the insert for specific dilution suggested)</i>                                |   |
|--|---|
| <b>100x</b>  | <b>10000x</b>   |
| A) 4 µl sample: 396 µl buffer (100x)<br>= 100-fold dilution<br><br><i>Assuming the needed volume is less than or equal to 400 µl.</i>  | A) 4 µl sample : 396 µl buffer (100x)<br>B) 4 µl of A : 396 µl buffer (100x)<br>= 10000-fold dilution<br><i>Assuming the needed volume is less than or equal to 400 µl.</i>   |
| <b>1000x</b>   | <b>100000x</b>  |
| A) 4 µl sample : 396 µl buffer (100x)<br>B) 24 µl of A : 216 µl buffer (10x)<br>= 1000-fold dilution<br><br><i>Assuming the needed volume is less than or equal to 240 µl.</i> | A) 4 µl sample : 396 µl buffer (100x)<br>B) 4 µl of A : 396 µl buffer (100x)<br>C) 24 µl of B : 216 µl buffer (10x)<br>= 100000-fold dilution<br><i>Assuming the needed volume is less than or equal to 240 µl.</i> |

## Reagent Preparation

- Freshly dilute all reagents and bring all reagents to room temperature before use.
- **MIX Diluent Concentrate (10x):** Dilute the MIX Diluent Concentrate 10-fold with reagent grade water to produce a 1x solution. When diluting the concentrate, make sure to rinse the bottle thoroughly to extract any

precipitates left in the bottle. Mix the 1x solution gently until the crystals have completely dissolved. Store for up to 30 days at 2-8°C.

- **Bovine Plasminogen Standard:** Reconstitute the Bovine Plasminogen Standard (400 ng) with 1 ml of MIX Diluent to generate a 400 ng/ml standard stock solution. Allow the vial to sit for 10 minutes with gentle agitation prior to making dilutions. Prepare duplicate or triplicate standard points by serially diluting from the standard stock solution (400 ng/ml) 2-fold with equal volume of MIX Diluent to produce 200, 100, 50, 25, 12.5, and 6.25 ng/ml solutions. MIX Diluent serves as the zero standard (0 ng/ml). Any remaining stock solution should be stored at -20°C and used it within 30 days. Avoid repeated freeze-thaw cycles.

| Standard Point | Dilution                       | [PLG] (ng/ml) |
|----------------|--------------------------------|---------------|
| P1             | 1 part Standard (400 ng/ml)    | 400           |
| P2             | 1 part P1 + 1 part MIX Diluent | 200           |
| P3             | 1 part P2 + 1 part MIX Diluent | 100           |
| P4             | 1 part P3 + 1 part MIX Diluent | 50            |
| P5             | 1 part P4 + 1 part MIX Diluent | 25            |
| P6             | 1 part P5 + 1 part MIX Diluent | 12.5          |
| P7             | 1 part P6 + 1 part MIX Diluent | 6.25          |
| P8             | MIX Diluent                    | 0.0           |

- **Biotinylated Bovine Plasminogen Antibody (50x):** Spin down the antibody briefly and dilute the desired amount of the antibody 50-fold with MIX Diluent to produce a 1x solution. The undiluted antibody should be stored at -20°C.
- **Wash Buffer Concentrate (20x):** Dilute the Wash Buffer Concentrate 20-fold with reagent grade water to produce a 1x solution. When diluting the concentrate, make sure to rinse the bottle thoroughly to extract any precipitates left in the bottle. Mix the 1x solution gently until the crystals have completely dissolved.
- **SP Conjugate (100x):** Spin down the SP Conjugate briefly and dilute the desired amount of the conjugate 100-fold with MIX Diluent to produce a 1x solution. The undiluted conjugate should be stored at -20°C.

## Assay Procedure

- Prepare all reagents, standard solutions, and samples as instructed. Bring all reagents to room temperature before use. The assay is performed at room temperature (20-25°C).
- Remove excess microplate strips from the plate frame and return them immediately to the foil pouch with desiccants inside. Reseal the pouch



securely to minimize exposure to water vapor and store in a vacuum desiccator.

- Add 50  $\mu$ l of Bovine Plasminogen Standard or sample to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed. Cover wells with a sealing tape and incubate for 2 hours. Start the timer after the last addition.
- Wash the microplate manually or automatically using a microplate washer. Invert the plate and decant the contents; hit 4-5 times on absorbent material to completely remove the liquid. If washing manually, wash five times with 200  $\mu$ l of Wash Buffer per well. Invert the plate each time and decant the contents; hit 4-5 times on absorbent material to completely remove the liquid. If using a microplate washer, wash six times with 300  $\mu$ l of Wash Buffer per well; invert the plate and hit 4-5 times on absorbent material to completely remove the liquid.
- Add 50  $\mu$ l of Biotinylated Bovine Plasminogen Antibody to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed. Cover wells with a sealing tape and incubate for 1 hour.
- Wash the microplate as described above.
- Add 50  $\mu$ l of SP Conjugate to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed. Cover wells with a sealing tape and incubate for 30 minutes. Turn on the microplate reader and set up the program in advance.
- Wash the microplate as described above.
- Add 50  $\mu$ l of Chromogen Substrate to each well. Gently tap plate to thoroughly coat the wells. Break any bubbles that may have formed. Incubate in ambient light for 25 minutes or until the optimal blue color density develops.
- Add 50  $\mu$ l of Stop Solution to each well. The color will change from blue to yellow. Gently tap plate to ensure thorough mixing. Break any bubbles that may have formed.
- Read the absorbance on a microplate reader at a wavelength of 450 nm **immediately**. If wavelength correction is available, subtract readings at 570 nm from those at 450 nm to correct optical imperfections. Otherwise, read the plate at 450 nm only. Please note that some unstable black particles may be generated at high concentration points after stopping the reaction for about 10 minutes, which will reduce the readings.

## Data Analysis

- Calculate the mean value of the duplicate or triplicate readings for each standard and sample.
- To generate a standard curve, plot the graph using the standard concentrations on the x-axis and the corresponding mean 450 nm

absorbance (OD) on the y-axis. The best fit line can be determined by regression analysis using log-log or four-parameter logistic curve fit.

- Determine the unknown sample concentration from the Standard Curve and multiply the value by the dilution factor.

## Typical Data


- The typical data is provided for reference only. Individual laboratory means may vary from the values listed. Variations between laboratories may be caused by technique differences.

| Standard Point | ng/ml | OD             | Average OD |
|----------------|-------|----------------|------------|
| P1             | 400   | 1.756<br>1.684 | 1.720      |
| P2             | 200   | 1.455<br>1.399 | 1.427      |
| P3             | 100   | 1.121<br>1.075 | 1.098      |
| P4             | 50    | 0.774<br>0.758 | 0.766      |
| P5             | 25    | 0.522<br>0.518 | 0.520      |
| P6             | 12.5  | 0.358<br>0.350 | 0.354      |
| P7             | 6.25  | 0.266<br>0.260 | 0.263      |
| P8             | 0.0   | 0.158<br>0.156 | 0.157      |

## Standard Curve

- The curve is provided for illustration only. A standard curve should be generated each time the assay is performed.

Bovine PLG Standard Curve



## Performance Characteristics

- This assay recognizes both natural and recombinant bovine plasminogen.
- The minimum detectable dose of bovine plasminogen as calculated by 2SD from the mean of a zero standard was established to be 3.75 ng/ml.
- Intra-assay precision was determined by testing three reference control samples twenty times in one assay.
- Inter-assay precision was determined by testing three reference control samples in twenty assays.

|                | Intra-Assay Precision |      |      | Inter-Assay Precision |      |       |
|----------------|-----------------------|------|------|-----------------------|------|-------|
| Sample         | 1                     | 2    | 3    | 1                     | 2    | 3     |
| n              | 20                    | 20   | 20   | 20                    | 20   | 20    |
| CV (%)         | 4.7%                  | 4.6% | 5.4% | 9.6%                  | 9.4% | 10.2% |
| Average CV (%) | 4.9%                  |      |      | 9.7%                  |      |       |

## Recovery

| Standard Added Value | 12.5 – 100 ng/ml |
|----------------------|------------------|
| Recovery %           | 89 – 112%        |
| Average Recovery %   | 97%              |

## Cross-Reactivity

| Species | Cross-Reactivity (%) |
|---------|----------------------|
| Canine  | None                 |
| Monkey  | None                 |
| Mouse   | <5%                  |
| Rat     | None                 |
| Swine   | <5%                  |
| Rabbit  | None                 |
| Human   | None                 |

## Troubleshooting

| Issue  | Causes   | Course of Action  |
|--|--|---|
| <b>Low Precision</b>                             | Use of improper components                     | <ul style="list-style-type: none"> <li>Check the expiration date listed before use.</li> <li>Do not interchange components from different lots.</li> </ul>  |
|  | Improper wash step                             | <ul style="list-style-type: none"> <li>Check that the correct wash buffer is being used.</li> <li>Check that all wells are empty after aspiration.</li> <li>Check that the microplate washer is dispensing properly.</li> <li>If washing by pipette, check for proper pipetting technique.</li> </ul> |
|  | Splashing of reagents while loading wells      | <ul style="list-style-type: none"> <li>Pipette properly in a controlled and careful manner.</li> </ul>  |
|  | Inconsistent volumes loaded into wells         | <ul style="list-style-type: none"> <li>Pipette properly in a controlled and careful manner.</li> <li>Check pipette calibration.</li> <li>Check pipette for proper performance.</li> </ul>   |
|  | Insufficient mixing of reagent dilutions       | <ul style="list-style-type: none"> <li>Thoroughly agitate the lyophilized components after reconstitution.</li> <li>Thoroughly mix dilutions.</li> </ul>  |
|  | Improperly sealed microplate                   | <ul style="list-style-type: none"> <li>Check the microplate pouch for proper sealing.</li> <li>Check that the microplate pouch has no punctures.</li> <li>Check that three desiccants are inside the microplate pouch prior to sealing.</li> </ul>  |
| <b>Unexpectedly Low or High Signal Intensity</b> | Microplate was left unattended between steps   | <ul style="list-style-type: none"> <li>Each step of the procedure should be performed uninterrupted.</li> </ul>   |
|  | Omission of step                               | <ul style="list-style-type: none"> <li>Consult the provided procedure for complete list of steps.</li> </ul>  |
|  | Steps performed in incorrect order             | <ul style="list-style-type: none"> <li>Consult the provided procedure for the correct order.</li> </ul>   |
|  | Insufficient amount of reagents added to wells | <ul style="list-style-type: none"> <li>Check pipette calibration.</li> <li>Check pipette for proper performance.</li> </ul>   |
|  | Wash step was skipped                          | <ul style="list-style-type: none"> <li>Consult the provided procedure for all wash steps.</li> </ul>  |
|  | Improper wash buffer                           | <ul style="list-style-type: none"> <li>Check that the correct wash buffer is being used.</li> </ul>   |
|  | Improper reagent preparation                   | <ul style="list-style-type: none"> <li>Consult reagent preparation section for the correct dilutions of all reagents.</li> </ul>  |
|  | Insufficient or prolonged incubation periods   | <ul style="list-style-type: none"> <li>Consult the provided procedure for correct incubation time.</li> </ul>   |

|                                     |  |  |
|-------------------------------------|--|--|
| <b>Deficient Standard Curve Fit</b> | Non-optimal sample dilution              | <ul style="list-style-type: none"> <li>• Sandwich ELISA: If samples generate OD values higher than the highest standard point (P1), dilute samples further and repeat the assay.</li> <li>• Competitive ELISA: If samples generate OD values lower than the highest standard point (P1), dilute samples further and repeat the assay.</li> <li>• User should determine the optimal dilution factor for samples.</li> </ul> |
|                                     | Contamination of reagents                | <ul style="list-style-type: none"> <li>• A new tip must be used for each addition of different samples or reagents during the assay procedure.</li> </ul>  |
|                                     | Contents of wells evaporate              | <ul style="list-style-type: none"> <li>• Verify that the sealing film is firmly in place before placing the assay in the incubator or at room temperature.</li> </ul>  |
|                                     | Improper pipetting                       | <ul style="list-style-type: none"> <li>• Pipette properly in a controlled and careful manner.</li> <li>• Check pipette calibration.</li> <li>• Check pipette for proper performance.</li> </ul>  |
|                                     | Insufficient mixing of reagent dilutions | <ul style="list-style-type: none"> <li>• Thoroughly agitate the lyophilized components after reconstitution.</li> <li>• Thoroughly mix dilutions.</li> </ul>   |

## References

- (1) Forsgren M *et al.* (1987) *FEBS Letters*. 213:254.
- (2) Collen D, Lijnen HR. (1991) *Blood*. 78:3114.
- (3) Carmeliet P, Collen D. (1996) *Semin Thromb Hemost*. 22:525.

Version 1.2R1